
A Short Course in the Fine Art of

Canon 7D Mark II Photography



Dennis P. Curtin

Copyright

PhotoCourse.com and ShortCourses.com are leading publishers of digital photography camera guides and textbooks. Descriptions, samples, and ordering information for this and other texts are available at:

www.shortcourses.com

www.photocourse.com

Our eBooks and eTexts™ are in the popular PDF format and available on CDs or as instant downloads. Many are also available in printed editions.

Feedback

If you have any questions, find any errors in this book, would like to make suggestions for improvements, or just want to let us know what you think, we welcome your feedback.

ShortCourses.com
16 Preston Beach Road
Marblehead, Massachusetts 01945
E-mail: peggy@shortcourses.com

Digital Rights Management

Our eBooks and eTexts™ can be read on almost any eReader or other device using many free eBook readers and apps including Adobe Reader (www.adobe.com). Our books are not burdened with any digital rights management restrictions so you are free to make copies and printouts for your own personal use. All we ask is that you not share copies with others.

Copyright

© Copyright 2015 by Dennis P. Curtin. All rights reserved. Printed in the United States of America. Except as permitted under the United States Copyright Act of 1976, no part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior written permission of the publisher.

Preface

Digital photography has had a wonderful impact on photography, however, it also has a downside. Since features can be added digitally at very little cost, there is a tendency among camera designers throughout the industry to add almost any feature they think may be of use to someone, somewhere. In the days of mechanical film cameras adding features was expensive, so most cameras had only the most basic—those that directly affected the content and quality of your images. On these classic cameras there were basically five things you could change; the film’s type and speed (ISO), the camera’s aperture, shutter speed and focus, and the focal length of the lens. There was very little to learn about the camera itself. For example, the *User Guide* for the Leica M4, introduced in 1967, was 31 pages long. The 7D Mark II has a 147 page *Basic Instruction Manual* and a 546 page *Instruction Manual*. All of this material is needed to describe 122 menu settings with hundreds of choices (See the *Instruction Manual*, pages 484–494) along with 30 plus buttons and dials. There are more than 44 pages just on playing back your images! Feature creep has turned into a feature avalanche.



The 31 page User Guide for the Leica M4.

This book cuts through the clutter to focus on just those aspects of your camera that affect the content and quality of your images. It focuses on five things: how the image sensor affects the capture of light and color, how the aperture and shutter speed affect the capture of depth and motion in a photo, how focus determines the sharpest part of the image, and how the lens determines what’s in the picture and what isn’t. If you master just these five classic techniques, and the ways they interact to influence your photos, you will be a very good photographer.

Among the things that make this book unique are the many integrated learning activities such as animations and *See for Yourself* sections that bring learning to life. With its many active links and guided visits to the Internet, it works best as an eBook. However, if you are one of those still committed to the printed page

< CONTENTS

you can print out each section as you study it or have a company such as Staples or Kinkos print a personal copy.

The book opens with two unique sections:

- **Classic Photography—The Shortest of Courses** introduces you step by step to the five techniques that are central to creative photography and the focus of this book.
- **The Creative Technique Finder** lists most of the things you might want to do in photography and lists the techniques you would use to achieve them.

■ Topic Sections

This book is organized into chapters containing closely related and easy to understand numbered topics, each of which can be studied in any order and most of which have the following sections:

- **An introduction** discusses the photographic concept or camera technique that is the focus of the topic. This discussion is an overview that provides the context and foundation for understanding your own camera.
- **Tips** discuss things that fall outside of the main narrative but which are interesting or important to know. Since so many concepts of photography are interrelated, tips also cross link concepts by referring you to related topics. Cross references in these sections direct you to sections in your camera's *Instruction Manual* where topics beyond the scope of this book are discussed in detail. The cross referenced topics are generally mechanical aspects of the camera that are not directly related to capturing fine images.
- **Resources to Explore** provides links to animations, movies, PDF's and Web sites that relate to the current topic. Especially important are the guided references to finding information on the Internet. Learning how to do so will serve you well going forward as you continue to explore photography on your own.
- **Keystroke boxes** like the example that follows on "Making Menu Choices," are found throughout the book and give you instructions on how to perform the task being discussed step-by-step.

If, while reading these topics, you encounter a photographic term or phrase with which you aren't familiar, search this eBook, the camera's *Instruction Manual* and the Internet to learn more about it.

MAKING MENU CHOICES

- **To display the last menu you viewed**, press the MENU button.
- **To scroll through main and secondary tabs** turn the Main Dial.
- **To select a setting listed on the menu** (not all commands list settings), turn the Quick Control Dial to highlight it, then press SET. The current setting is indicated in blue.
- **To backup without changing a setting**, press MENU or the shutter button before pressing SET.
- **To exit the menu**, or in some cases back up through previous choices, press the MENU button. To exit without making a change press MENU before pressing SET.
- **To instantly return to shooting**, press the shutter button halfway down
- **To display a description of the highlighted menu setting**, hold down the INFO button.

- **Seeing for Yourself** includes demonstrations of the concept under discussion and guides you from passively reading to actually using your own camera to actually see the effects you can get when you change settings. Getting better at photography requires practice and that's one of the things this section is designed to help you with by making it more convenient. In some topics it does this by displaying "targets" which are discussed below.

- **Projects** at the end of each chapter pull together the concepts discussed in the chapter. Many of the projects are based on themes inspired by the images, techniques and teachings of great photographers such as Diane Arbus, Dorothea Lange, Garry Winnogrand, Ansel Adams, Eugene Atget, Walker Evans and many others. The discussion of these historic figures will hopefully encourage you to learn more about them, their work and the history and aesthetics of photography as a fine art.

■ Using Your e-Reader


This book is in a PDF format that can be displayed on almost any computer, smart phone or tablet and the book automatically scales to fit the device's screen. You can transfer the eBook to any of these devices using an app such as Dropbox. Once there, you can then use a menu to open the book in Kno, Adobe Reader, iBooks, Kindle, Evernote and other apps on your device. Each of these apps has its own unique features so refer to their documentation if you are not familiar with them. The things you want to know include how to use your app

< CONTENTS

to open PDF documents, display single pages, scroll back and forth through pages, click or tap links, print copies, and add notes.

■ A Word About Targets

Many of the *Seeing for Yourself* sections, and a few of the projects at the end of chapters, refer you to targets in Appendix A. A target is simply a photo or other illustration that you display on your e-reader to explore the concepts and techniques of photography using your own camera. For example, you can photograph a ball bouncing on the screen to see the effects of shutter speed on motion capture and focus tracking. Although just rough approximations of the real world, targets have certain advantages:



This target is used to practice face detect and shows (front row left to right) Harry A. Longabaugh, alias the Sundance Kid, Ben Kilpatrick, alias the Tall Texan, Robert Leroy Parker, alias Butch Cassidy; Standing: Will Carver & Harvey Logan, alias Kid Curry; Fort Worth, Texas, 1900. From the studio of John Schwartz.

- They save you time because you don't have to find real-world scenes where you can practice procedures.
- You can use targets anywhere, anytime, even at night. You are not dependent on the quality of the light and weather.
- Targets are less complex than real-world scenes so the effects stand out more clearly.
- Targets are uniform so you can easily compare your results with and ask questions of others using the same targets.

Because learning photography isn't entirely linear, there are a few things you

have to learn out of sequence in this book to use the targets. They include those in the following table:

Procedure	Topic
Selecting manual (M) mode and setting the aperture and shutter speed	x-y
Selecting program auto (P) and changing the aperture and shutter speed	x-y
Setting the camera to spot metering mode	x-y
Setting focus to a single AF (autofocus) area	x-y
Turning on Live View	x-y
Using manual focus	x-y



In photography, don't follow the crowd. Find your own unique style.

Classic Photography—The Shortest of Courses

As you have seen, if you read the preface, all you need to capture great photographs are five things—the “film,” shutter speeds, apertures, focus and lens focal lengths. From the invention of photography in 1839 through the rise of the digital camera in the 1990s, these were basically the only settings photographers had to work with—and until recently they were all set manually. That means that almost all of the historically important and memorable photos you have seen were taken with these simple controls. In the digital era feature creep has added an endless stream of new controls—many of them designed to make things easier or more idiot-proof. It’s all of these extra controls and settings that now make cameras so complicated. The best thing about working with classic controls is that they work on all cameras so you only have to learn them once. In this tutorial we explore the five controls this book is about, in the order in which they are presented.

■ Step 0. Getting Ready

If this is the first time you have used your camera see *Chapter 1 Getting Started* on page 37 in your camera’s *Instruction Manual* for guidance on getting it ready to take pictures. This process is also discussed in Topic 1–4 of this book. When ready to begin the tutorial, turn the power switch just below the Mode Dial to ON. Buttons and dials referred to in this tutorial are described in Topic 1–7.

NOTE: During this tutorial if you pause for 4 seconds, exposure information on the LCD panel and all information in the viewfinder is turned off. After one minute both displays are off. To turn them back on press the shutter button halfway down and then release it.

■ Step 1. The “Film”

In the film era of photography, images were captured on a thin layer of a light sensitive emulsion on a paper, metal, glass, celluloid, or plastic substrate. When exposed to light silver halide particles in the emulsion captured the range of brightnesses in the scene. Today’s digital “film” is a solid-state image sensor that creates digital image files.

In this book we strongly encourage you to use the RAW file format for your image files because this format’s image quality is much better the alternative—the JPEG format. Files in the RAW format cannot be altered so, in this respect, they are much like film negatives once were. Any changes you make to these

files during editing don’t permanently affect the file and can be undone. This is referred to as *non-destructive editing*. JPEG images, on the other hand, are heavily and irreversibly manipulated by the camera.

Here, at the risk of getting ahead of ourselves, we show you how to select settings so you capture images in two formats—one in RAW and one in JPEG. Having both formats ensures you will be able to edit your images in any software—even applications that don’t support the RAW format.

To complete this step you only need to identify the MENU button and the Main and Quick Control Dials shown in Topic 1-7. When finished you can repeat the above commands but select no RAW (the blue — character) while leaving the Large/Fine JPEG selected.

SELECTING THE RAW FORMAT

1. Hold down the Lock-release button in the center of the Mode Dial and turn the dial to select Tv (time value) or Av (aperture value).
2. With the camera on, press the MENU button to display menu tabs.
3. Turn the Main Dial to select the Shooting menu tab 1 on the far left.
4. Turn the Quick Control Dial, if necessary, to highlight *Image quality* and press SET to select it and display a screen of image file formats.
5. Turn the Main Dial to select RAW.
6. Turn the Quick Control Dial to select Large/Fine JPEG (the second from the left).
7. Press SET to confirm the changes and then press the shutter button halfway down to return to shooting mode.



The *Image Quality* menu is displayed when you press MENU and select the Shooting menu tab 1’s *Image Quality* setting. Here the menu is set to no RAW format (the blue —) and Large/Fine JPEG.

The image sensor’s film speed, referred to as its ISO, determines how much light is needed for a good exposure. To take photos in dim light, you use a high ISO. In bright light, you use a low ISO to reduce noise. The current ISO setting is displayed on the LCD panel and in the viewfinder. To change the ISO:

< CONTENTS

- ❑ Hold down the Lock-release button in the center of the Mode Dial and turn the dial to Av or Tv. (In Scene Intelligent Auto shooting mode the ISO setting is fixed at Auto).
- ❑ Press and release the ISO button on top of the camera then immediately turn the Main Dial to scroll through the available ISO settings.
- ❑ If you set the ISO to A (Auto), you can compose an image in the viewfinder and then press the shutter button halfway down to see what setting the camera has selected.

For more on changing the ISO refer to Topic x-y.




Icons marking the ISO button on the back of the camera.

■ Step2. Shutter Speeds and Apertures

The shutter speed affects how light or dark an image is but also controls how motion is captured. You use a slow shutter speed to creatively blur an image, or a fast one for sharpness. On the 7D Mark II you can set the shutter speed automatically or manually. To set it manually:

- ❑ Hold down the Lock-release button in the center of the Mode Dial then turn the dial to Tv (time value).
- ❑ Turn the Main Dial to select a shutter speed. As you do so notice how the aperture changes automatically to keep the exposure constant. (You may have to press the shutter button halfway down to see the change. If the **aperture** blinks you are outside of the camera's exposure range.)
- ❑ For more on changing shutter speeds refer to Topic x-y.




The LCD panel on top of the camera displays:

- The shutter speed (1/125) and aperture (2.8) both circled in green.
- The ISO (circled in red) and set to A (Auto)



The Mode Dial can be set so you can manually select the shutter speed (Tv) or aperture (Av). To change shooting modes you hold down the Lock-release button in the center of the Mode Dial and turn the dial to align a shooting mode with the white index mark. Here it is set to the P (Program) shooting mode.

The camera's power switch is just below the Mode Dial.



The Main Dial, close to the shutter button, selects a shutter speed or aperture depending on whether the shooting mode is set to Av (aperture priority) or Tv (shutter priority).

The aperture affects how light or dark an image is but also determines how much of a scene is sharp from near to far—called *depth of field*. A small aperture gives great depth of field so everything from the foreground to the horizon may be sharp. A large aperture gives shallow depth of field so you can throw the background and foreground out of focus. On the 7D Mark II you can set the aperture automatically or manually. To set it manually:

- ❑ Hold down the Lock-release button in the middle of the Mode Dial as you turn the dial to Av (aperture value).
- ❑ Turn the Main Dial to select an aperture. As you do so notice on the LCD panel how the shutter speed changes automatically to keep the exposure constant. (You may have to press the shutter button halfway down to see the change. If the shutter speed blinks you are outside of the camera's exposure range.)
- ❑ While looking through the viewfinder, turn the Main Dial to select first a small aperture (a large number such as 3.5) and then a large aperture (a small number such as 16) and for each setting press the depth of field preview button below the right side of the lens. You should be able to see the change in depth of field although at small apertures, such as f/16, the viewfinder is dark.
- ❑ For more on changing apertures refer to Topic x-y.

< CONTENTS

■ Step 3. Focus

Focus determines where the sharpest part of an image, called the *plane of critical focus*, falls. On the 7D Mark II you can focus automatically or manually. To do so manually:



The lens focus switch can be set to AF for autofocus or MF for manual.

- ❑ Set the AF (autofocus) switch on the lens to M or MF (manual).
- ❑ While looking through the viewfinder, pick out a subject you want sharpest in the picture and turn the lens's focusing ring until it is sharp.
- ❑ Repeat manual focusing but this time place the small square in the center of the viewfinder over the subject you want sharpest. Hold the shutter button halfway down as you turn the focus ring to manually focus on that subject. Notice how when focus is achieved the camera beeps and the green confirmation lamp comes on. The center AF point used to set focus briefly flashes red if the light is dim.
- ❑ Switch the shooting mode to Scene Intelligent Auto, open *Appendix A See for Yourself Targets* and display *Target 1 Face Detect*. Set the AF switch on the lens to AF (autofocus) and frame the target on the screen. Be sure you are not too close when you press the shutter button halfway down to focus. The AF points the camera displays will almost always show that it is focusing on the center face.

■ Step 4. Lens Focal Length

The focal length of a lens determines how much of a scene is captured in an image. For a wide angle of coverage you use a short focal length. To enlarge subjects so they appear closer you use a long focal length. On the 7D Mark II you can change the focal length by changing lenses or, on a zoom lens, by turning the lens's zoom ring. For more on changing focal lengths refer to x-y.

Tips

- It was in 1931 when Harold Edgerton, a professor of electrical engineering at MIT, produced the first electronic flash tube. This invention led to today's small and powerful electronic flash units.
- Autoexposure was first introduced as "through the lens metering". Until then photographers carried a separate light meter to calculate their exposures.
- Autofocus was first introduced on the Konica C35 AF in 1977—the same year Apple Computer incorporated.
- All settings described in this book assume that the camera's power switch is on and its Multi-function Lock Switch below the Quick Control Dial is set to the left so it is unlocked.
- Some of the sections in the camera's *Instruction Manual* are listed below.

Topic	Page(s)
How to view the CD-ROM instruction manuals	531
Printing Images	411
Transferring images to the computer	411, 531
Flash photography	253–283
Playing back your images	353–395
Shooting movies	313–352
Trouble shooting	495–509
Error codes	410
System Map of all of the Canon products compatible with your camera	478–479
Using GPS	197
Attaching and detaching a lens	50

Resources to Explore

1. Check out the printed *Quick Reference Guide* and *Brief Instruction Manual* that come in the box with the camera.
2. Check out the camera's *Instruction Manual* CD-ROM containing PDF versions of the camera's *Instruction Manual* and *Quick Reference Guide*. Instructions for viewing these manuals are on pages 532–533 of the *Instruction Manual*. Basically, you display the contents of the CD ROM and click the START.pdf file. You should copy the PDF files to your e-reader so you have access to their contents just as you do to this book.

< CONTENTS

3. Check out the *EOS DIGITAL Solution Disk CD-ROM* that contains applications for your camera. For more information and installation procedures of the software, see pages 536–538. To find the manuals on-line, see 5 below and select *Drivers & Software* from the screen that appears.


- **EOS Utility** is used to transfer still photos and movies from your camera to the computer. It can also be used to change camera settings and shoot remotely from any computer connected to the camera.
- **Digital Photo Professional** is mainly used to view, edit, process and print RAW images, as well as JPEGs, while retaining the original images.
- **Picture Style Editor** is used to edit, create and save Picture Style files.
- **ImageBrowser EX** is used to view, edit and print JPEG photos and play back MOV and MP4 movies. You can also use this app to display shooting locations and the route traveled on a map using the geotag information recorded in images by the camera's built in GPS function.
- **EOS Remote** is a free application for Apple iOS or Android smartphones and tablets. When connected to your camera over Wi-Fi you can use these devices to take and review photos and also change settings, set focus, and release the shutter remotely. You can also use your device to remotely browse, delete, and rate still images and movies and save images shot with EOS cameras on your smartphone or tablet.

4. Check out the *Software Instruction Manual* CD-ROM containing software manuals in PDF format. Instructions for installing and using these applications are available on pages 536–539 of your camera's *Instruction Manual*.



To check out all available manuals, accessories and lenses for your camera visit http://www.usa.canon.com/cusa/support/consumer/eos_slr_camera_systems/eos_digital_slr_cameras/eos_7d_mark_ii#BrochuresAndManuals

5. If you don't have Photoshop, Lightroom or other photo-editing program that supports this camera's RAW format, install the *Digital Photo Professional* program that came with your camera and use it to view and edit RAW images. For more information and installation procedures of the software, see pages 536–538 in your camera's *Instruction Manual*. Instructions on using the program can be found on the *EOS Digital Software Instruction Manual* CD or downloaded from the Canon Web site.



If you go to the link above and select Brochures & Manuals you get a complete listing of the manuals that are available.

6. Search the Internet for images by "Harold Edgerton", the inventor of electronic flash, to see his amazing shots of things such as bullets passing through playing cards and apples.

Seeing for Yourself

1. Following the brief instructions in Step 1 of this section change the ISO while watching the effect that the change has on the information displayed on the LCD panel and in the viewfinder.
2. Following the brief instructions in Step 2 of this section adjust the shutter speed and aperture while watching how settings change on the LCD panel and in the viewfinder.
3. Following the brief instructions in Step 3 of this section adjust the focus on various subjects while looking at the scene through the viewfinder.
4. Following the brief instructions in Step 4 of this section change the focal length of your lens while watching the effect this has on the scene as seen through the viewfinder. If you have to change lenses to change focal lengths, you'll find instructions on *Attaching and Detaching a Lens* on page 50 in your camera's *Instruction Manual*.

< CONTENTS

Contents

Copyright	2
Preface	2
Classic Photography—The Shortest of Courses	5
The Creative Technique Finder	11

Chapter 1 Getting to Know Your Camera 13

Topic 1–1. In the Beginning	14
Topic 1–2. What is a Digital Photograph?	18
Topic 1–3. The Canon 7D Mark II Camera—Introduction	20
Topic 1–4. Jump Start—Using Scene Intelligent Auto Mode	24
Topic 1–5. Good Things to Know	28
Topic 1–6. When Things Go Wrong	30
Topic 1–7. Anatomy of the Camera	32
Topic 1–8. Using Menu Settings	36
Topic 1–9. Changing Settings on the Quick Control Screen	38
Topic 1–10. Using the Camera’s Displays	39
Topic 1–11. Live View	41
Topic 1–12. Changing Drive Modes	47
Topic 1–13. Playing Back & Managing Your Images	50
Topic 1–14. Caring for Your Camera	52
Topic 1–15. Projects in Photography	56

Chapter 2 Choosing Your “Film” 65

Topic 2–1. Pixels and Colors	66
Topic 2–2. Changing Image Quality	70
Topic 2–3. Image Sizes	76
Topic 2–4. ISO Sensitivity	79
Topic 2–5. Noise Reduction	82
Topic 2–6. White Balance	85
Topic 2–7. Setting and Using a Custom White Balance	90
Topic 2–8. Setting a Specific Color Temperature	92
Topic 2–9. Selecting a Color Space	94
Topic 2–10. Projects in Photography	96

Chapter 3

Topic 3–1. Understanding Exposure	108
Topic 3–2. The Relationship of Shutter Speed and Aperture	112
Topic 3–3. Available Shooting Modes	116
Topic 3–4. Using Creative Auto (CA) Mode	119
Topic 3–5. Using Image Zone Modes	120
Topic 3–6. Using Custom (C) Mode	121
Topic 3–7. Using Blub (B) Mode	122
Topic 3–8. Using Program Auto (P) Mode	123
Topic 3–9. Using Shutter-Priority (S) Mode	125
Topic 3–10. Shutter Speed and Sharpness	132
Topic 3–11. Creative Camera Movement Blur	136
Topic 3–12. Creative Subject Motion Blur	138
Topic 3–13. Using Aperture-Priority (A) Mode	142
Topic 3–14. Depth of Field	147
Topic 3–15. Circles of Confusion	153
Topic 3–16. Shallow Depth of Field	156
Topic 3–17. Using Manual (M) Mode	160
Topic 3–18. Using Histograms	162
Topic 3–19. How Your Exposure System Works	168
Topic 3–20. Choosing a Metering Method	171
Topic 3–21. When Automatic Exposure Works Well	173
Topic 3–22. When to Override Automatic Exposure	175
Topic 3–23. How Overriding Autoexposure Works	180
Topic 3–24. Exposure Compensation	182
Topic 3–25. Locking Exposure	186
Topic 3–26. Autoexposure Bracketing (AEB)	190
Topic 3–27. The Self-Timer for Sharpness	193
Topic 3–28. Projects in Photography	196

Chapter 4 Focusing 205

Topic 4–1. The Plane of Critical Focus	206
Topic 4–2. Manual Focus	209
Topic 4–3. Hyperfocal Distance and Zone Focusing	213
Topic 4–4. Autofocus	217
Topic 4–5. Autofocus Areas	221
Topic 4–6. Focus Lock	225
Topic 4–7. Projects in Photography	228

< CONTENTS

Chapter 5 Changing Lens Focal Lengths 235

Topic 5–1. Lenses	236
Topic 5–2. Focal Length	242
Topic 5–3. Zoom Lenses	247
Topic 5–4. Normal Focal Lengths	249
Topic 5–5. Short Focal Lengths	252
Topic 5–6. Long Focal Lengths	257
Topic 5–7. Perspective in a Photo	265
Topic 5–8. Close-up Photography	267
Topic 5–9. Tilt-Shift Lenses	273
Topic 5–10. Lens Accessories	276
Topic 5–11. Projects in Photography	279


Appendix A See for Yourself Targets 285

Target 1. Face Detect	286
Target 2. Maxwell's Experiment in Colors	287
Target 3. Aspect Ratios	288
Target 4. Aspect Ratio Cutouts	289
Target 5. Ten Step Grayscale	290
Target 6. Color Histogram	291
Target 7. Tonal Range—Narrow	292
Target 8. Tonal Range—Wide	293
Target 9. White Card	294
Target 10. Gray Card	295
Target 11. Black Card	296
Target 12. Stamp Against Black	297
Target 13. Black and White	298
Target 14. Bulls eye Grayscale	299
Target 15. Picture with Grayscale	300
Target 16. Picture with Grayscale	301
Target 17. Highlight Alert	302
Target 18. Picture With Three Boxes	303
Target 19. Zone System Zones	304
Target 20. Zone System Scale	305
Target 21. Faces of All Kinds	306
Target 22. Depth of Field Scales	307
Target 23. Bouncing Ball	308
Target 24. Color Space	309

Target 25. Black and White with Stamp	310
Target 26. Viewing Cutouts	311
Target 27. Red-eye	312
Target 28. Lens Angle of View	313

The Creative Technique Finder

In photography you only have to master a few techniques to achieve your desired ends. Following is a check list of those things you are most likely to want to do, and the techniques you use to do them. You can search in this book and your camera's *Instruction Manual* to find where each technique is discussed. Try all of these techniques and try them in combinations. For example, to reduce blur you can select a faster shutter speed, but also increasing the ISO makes even faster speeds available and adding flash adds even faster speeds.



Click the cover to download a PDF version of the Creative Technique Finder table formatted for display on a smart phone. There are a number of ways to transfer it, including the free Dropbox app. (The Pocket Guide is at www.photocourse.com/itext/techniquefinder/pocketguide.pdf.)

Issue	Technique
Increase camera/subject distance	Increase lens focal length
	Use a teleconverter
Increase depth of field	Increase camera-subject distance and crop image later
	Increase the ISO
	Select smaller aperture
	Increase distance to subject
	Use flash, continuous lights
Decrease depth of field	Decrease focal length, zoom out
	Focus at hyperfocal distance
	Decrease ISO
	Select larger aperture
Remove or minimize reflections	Decrease distance to subject, focus on nearer part of scene
	Use neutral density filter
	Increase lens focal length/zoom in

Issue	Technique
Reduce camera/subject blur S=Reduces subject blur C=Reduces camera blur B=Reduces both	Increase the ISO (B)
	Increase shutter speed (B)
	Use flash or continuous studio lights (B)
	Use mirror lock-up (C)
	Use cable release (C)
	Use self-timer or remote control (C)
	Use tripod or other support (C)
	Use image stabilization (C)
	Use manual focus (C)
	Use minus (-) exposure compensation with flash (B)
	Use continuous mode (B)
	Decrease lens focal length, zoom out (B)
	Increase distance to subject (B)
More head-on angle to subject (S)	
Improve exposures	Use histograms
	Use highlight warnings
	Use exposure and flash compensation
	Use flash
	Use automatic exposure bracketing
	Use AE Lock
	Use spot metering
Increase size of subject in image	Use Manual exposure mode
	Increase lens focal length, zoom in
	Use macro mode or macro lens
	Use close-up lenses
	Use minimum focus distance
	Reverse lens
Increase area captured in image	Use a teleconverter
	Use digital zoom
	Decrease lens focal length, zoom out
Remove or minimize reflections	Move farther from subject
	Use circular polarizing filter
Improve Colors	Change your angle to the reflection
	Set white balance
	Use Adobe RGB color space
	Use RAW image format

< CONTENTS

Issue	Technique
Lighten shadows	Soften the light
	Use fill flash
	Shoot using the RAW format
	Use HDR (High Dynamic Range)
Reduce contrast	Shoot on overcast days
	Use fill flash
	Use reflectors
	Move light source closer to subject
Improve image quality	Use High Dynamic Range (HDR)
	Use RAW image format
Lighten or darken a scene	Use exposure compensation
Lighten background in flash photos	Use slow sync flash
	Use slow shutter speed
	Use plus exposure, flash compensation
	Use bounce flash
Darken background in flash photos	Use minus exposure compensation
Lighten or darken foreground in flash photos	Use plus or minus flash compensation
	Get closer or farther away
	Use reflectors
Prevent red-eye	Use red-eye reduction mode
Respond faster	Anticipate needed settings
	Manual focus/prefocus
	Use custom settings
Increase the range of the flash	Increase the ISO
	Increase the aperture
	Use an external flash
	Use a flash with a higher guide number
	Increase the focal length if the flash auto zooms
	Use a flash extender

Issue	Technique
Improve focus	Use focus lock
	Use focus zones, areas
	Use face detect
	Tracking or servo autofocus
	Use manual focus—ideally with Live View so you can enlarge the subject on the screen.
Reduce lens flare	Use focus assist
	Use lens hood
	Shade the front element of the lens
	Don't shoot directly into the light



As you begin this eBook, it may help to read something that John Szarkowski wrote in his “Introduction to William Eggleston’s Guide”. It goes “Photography is a system of visual editing. At bottom, it is a matter of surrounding with a frame a portion of one’s cone of vision, while standing in the right place at the right time. Like chess, or writing, it is a matter of choosing from among given possibilities, but in the case of photography the number of possibilities is not finite but infinite. The world now contains more photographs than bricks, and they are, astonishingly, all different. Even the most servile of photographers has not yet managed to duplicate exactly an earlier work by a great and revered master”.